

LyondellBasell Cincinnati Technical Center Capabilities at a Glance

Cincinnati Technology Center

260,000 square feet

- **Technical Service**
- **Application Development**
- **Product Development**
- **Material Properties Development**
- **Catalyst Systems Scale-up**
- **Processing, Testing, and Characterization**



Cincinnati Technology Center Laboratories

■ Applications Laboratory

- Broad range of plastics processing lines used for...
 - New resin development
 - Applications/structure development
 - Technical support of existing resins and applications

■ Analytical Laboratory

- Fundamental polymer chemistry testing

■ Polymer Testing Laboratory

- Physical property testing




Flexible Applications Laboratory Equipment

- Multi-layer Blown Film Lines
- Single-layer Blown Film Lines
- Coextrusion Cast Film Line
- Extrusion Coater/Laminator
- Machine Direction Orientation Line



7-Layer Blown Film Line




Photograph supplied courtesy of Collin GmbH, Germany

2018 Addition

- **Barrier Film Structure Development and Customer Support**
- ***Plexar* Tie Layer Resin Development**
- **High Barrier HDPE Development**

3-Layer Blown Film Line



- 3 Layer Coextrusion, 20/60/20 layer distribution
- Die size: 6 inches
- Maximum output: 200 lbs./hr.
- Maximum lay-flat width: 36 inches
- Primarily for LLDPE, LDPE and MMW-HDPE Coextrusions




3-Layer High Stalk Blown Film Line

- 3 Layer coextrusion, equal layer distribution
- Die: 200 mm with IBC
- Output range: 500-600 lbs./hr.
- Maximum lay-flat: 60 Inches
- Film gauge: 0.25 mil-8.0 mils
- Grooved feed
- High-stalk or in-the-pocket
- Primarily for HMW-HDPE



Coextrusion Cast Film Line



- **Up to 5 layers**
 - 3 extruders
 - A Extruder: 2.5 in., 28:1 L/D
 - B,C Extruders: 2.0 in., 28:1 L/D
- **Plugs: AAAAA, AAACC, CAABB, AACBB, ABCBA**
- **Maximum output: 600 lbs./hr.**
- **Maximum width: 30 inches**
- **Film gauge: up to 6.0 mils**
- **Tension ranges: 0.2 to 2.0 PLI**
- **Maximum roll diameter: 24 in.**

5-Layer Extrusion Coating/Lamination Line



- Up to 5 layers (3 extruders)
- Substrate widths up to 30 inches
- Maximum line speed: 3000 fpm
- Substrate pre-treatment
 - Flame, Corona, Plasma, Primer
- Ozone treatment of melt curtain
- Post-treatment
 - Corona, Plasma

Machine Direction Orientation Line

- 12” wide unit
- Non-commercial size
 - Prototype production
 - Structure development
 - Technology development
- Capable of orienting blown film, cast film and sheet
- Dual stretching stage capability
- Commercial scale-ability
- Data acquisition software



In-line Film Gel Inspection



- **Optical Control Systems (OCS) cameras analyze for gels/defects during film production**
- **Camera systems are similar to what are used at many Equistar plants for QC Gel testing**
- **Used on various film lines**
 - OCS cast film line (4-inch die)
 - Monolayer blown line (4-inch die, smooth-bore extruder)
 - 3-layer HMW-HDPE blown line

Krauss-Maffei Pressure Pipe Extrusion Line



2018 Addition

- **1 and 4 Inch Pipe Capability**

Bekum Large Part Blow Molder Blow Molder



2018 Addition

- **Gerry Cans**
- **L-Ring Drum**

Uniloy Single Head and 4-Head Blow Molders



- Reciprocating Screw Machines
- Taste and Odor Panel Testing
- High Shear Processing Studies
- Dairy School Milk Bottle Training
 - Operation/Optimization
 - Maintenance/Troubleshooting

Injection Molding Capability

■ Injection Molding Machines

- Battenfeld 65 Ton
- Battenfeld 67 Ton
- Van Dorn 170 Ton
- Van Dorn 120 Ton
- Engel 300 Ton
- Husky 300 Ton

■ Primary Uses

- Thin-wall molding
- Heavy-wall containers
- ASTM & ISO test specimens
- Spiral flow measurements



Additional Applications Laboratory Equipment

■ Wire and Cable Extrusion Lines

- Constant Vulcanization Line
- Davis-Standard Cable Coating Line

■ Rotomolding Machine

■ Fiber Line

■ Bi-axial Orienter

■ Batch and Continuous Extrusion Compounders

■ Thermal Methods

- Differential Scanning Calorimetry (DSC)
 - T_m , T_c , Oxidation, crystallization kinetics
- Dynamic Thermal Analysis (DMA)
 - Glass transition, stiffness over wide temperature range
- Thermogravimetric Analysis (TGA)
 - Mass loss (reaction, degradation), filler, calcium carbonate and carbon black content

■ Spectroscopic Methods

- Fourier Transform Infrared Spectroscopy (FTIR) Micro, ATR and Transmission
 - Identification of unknowns, contaminants, gels and polymers
- Raman – Micro
 - ID layers in packaging and thin films (1 micron spatial resolution capability), unknowns and contaminants
- Nuclear Magnetic Resonance (NMR)
 - Blend composition, comonomer content, branching content, unsaturation level and identification of unknowns
- X-Ray Diffraction (XRD)
 - Crystalline content/structure
- Inductively Coupled Plasma (ICP)
 - Identification and quantification of elemental composition – low detection limits
- X-Ray Fluorescence (XRF)
 - Identification and quantification of elemental composition

■ Rheological Methods

- Strain control rotational rheometer
 - Low shear viscosity, storage and loss moduli, melt elasticity
- Stress control rheometer
 - Creep and recoverable compliance
- Capillary rheometer
 - High shear viscosity, die swell, melt fracture
- Extensional rheometers
 - Extensional viscosity and melt tension

■ Solution Methods

- Gel Permeation Chromatography (GPC-IR & Multi-Angle Light Scattering)
 - Molecular weight, molecular weight distribution, long-chain branching
- Crystallization Elution Fractionation (CEF)
 - Chemical Composition Distribution Characterization, Comonomer Content
- Flow Injection Polymer Analysis (FIPA)
 - Xylene Solubles
- Intrinsic Viscosity (IV)

■ Chromatography Methods

- Gas Chromatography (GC) and Gas Chromatography / Mass Spectrometry (GC/MS)
 - Analyses: Identification as well as qualitative and quantitative analyses of volatile and semi-volatile compounds in solid, liquid and gaseous samples
 - Inlets: Static and dynamic headspace samplers, solid phase micro-extraction (SPME), liquid auto-injectors, gas sampling valves
 - Detectors: Flame ionization, thermal conductivity, mass spectrometer (transmission quadrupole and time-of-flight)
- Liquid Chromatography
 - High Performance Liquid Chromatography (HPLC)
 - Quantitation of additives, unknowns, contaminants
 - High Performance Liquid Chromatography / Mass Spectrometry (HPLC/MS)
 - Quadrupole/time of flight (QtoF): molecular identification and quantitation, extremely high mass accuracy, excellent selectivity and sensitivity
 - Ion Trap (QIT): capable of multiple MS/MS experiments, detailed molecular structural information, excellent selectivity and sensitivity

■ Microscopy Methods

- Field Emission Scanning Electron Microscope (FESEM) with scanning transmission electron microscope (STEM) accessory
- Variable Pressure Scanning Electron Microscope (SEM) with energy dispersive x-ray spectrometry (EDS)
- Ultra-Microtome with Cryo-Stage
- Hot Stage Microscope
- Optical Microscopy
- Raman
- Fourier Transform Infrared (FTIR)



Physical Testing Lab

■ Polymers (Resin) Testing

- Melt Index, Density, Ash
- Lab Color
- ASTM Type IV Physicals

■ Product Testing (Film, Pipe, Molded Articles)

- Physical Properties (tensile, impact, tear, COF, thickness, strain-hardening)
- ESCR (NCLT, Bent Strip, 3-pt Bend)
- Pipe (PENT, FNCT, LTHS)
- Optics (Haze, Gloss, NAS)
- Permeability (O₂, WVTR)
- Aging, Weathering
- Adhesion, Heat Seal/Seal Strength



Physical Testing Lab – Pressure Pipe Testing

- PENT Testing Equipment
 - Slow Crack Growth Resistance



- FNCT Testing Equipment
 - Environmental Slow Crack Growth Resistance

Physical Testing Lab – Robotic Test Stations



- 3 Point Bend Flex Testing

- Film Tensile Properties Testing



Disclaimer and Trademarks

Before using a product sold by a company of the LyondellBasell family of companies, users should make their own independent determination that the product is suitable for the intended use and can be used safely and legally. **SELLER MAKES NO WARRANTY; EXPRESS OR IMPLIED (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE OR ANY WARRANTY) OTHER THAN AS SEPARATELY AGREED TO BY THE PARTIES IN A CONTRACT.**

LyondellBasell prohibits or restricts the use of its products in certain applications. For further information on restrictions or prohibitions of use, please contact a LyondellBasell representative.

Users should review the applicable Safety Data Sheet before handling the product.

Adflex, Adstif, Adsyl, Akoafloor, Akoalit, Alastian, Alathon, Alkylate, Amazing Chemistry, Aquamarine, Aquathene, Avant, Catalloy, Clyrell, CRP, Crystex, Dexflex, Duopac, Duoprime, Explore & Experiment, Filmex, Flexathene, Fueling the power to win, Glacido, Hifax, Hiflex, Histif, Hostacom, Hostalen, Hyperzone, Ideal, Indure, Integrate, Koattro, LIPP, Lucalen, Luflexen, Lupolen, Luposim, Lupostress, Lupotech, Metocene, Microthene, Moplen, MPDIOL, Nerolex, Nexprene, Petrothene, Plexar, Polymeg, Pristene, Prodflex, Pro-fax, Punctilious, Purell, Refax, SAA100, SAA101, Sequel, Softell, Spherilene, Spheripol, Spherizone, Starflex, Stretchene, Superflex, TBAC , Tebol, T-Hydro, Toppyl, Trans4m, Tufflo, Ultrathene, Vacido and Valtec are trademarks owned and/or used by the LyondellBasell family of companies.

Adsyl, Akoafloor, Akoalit, Alastian, Alathon, Aquamarine, Avant, CRP, Crystex, Dexflex, Duopac, Duoprime, Explore & Experiment, Filmex, Flexathene, Hifax, Hostacom, Hostalen, Ideal, Integrate, Koattro, Lucalen, Lupolen, Metocene, Microthene, Moplen, MPDIOL, Nexprene, Petrothene, Plexar, Polymeg, Pristene, Pro-fax, Punctilious, Purell, Sequel, Softell, Spheripol, Spherizone, Starflex, Tebol, T-Hydro, Toppyl, Tufflo and Ultrathene are registered in the U.S. Patent and Trademark Office.